



Figure 110. Examples of Bank Height Ratio (BHR) Categories for Stability Evaluation.