

Manufacturer: Rexam Healthcare
Model: Clic-Loc
ASTM Type: IA

Description:

This is a two-piece plastic/plastic continuously-threaded closure (Figure 1A and 1B).



Figure 1A

Figure 1B

The closure is opened by pushing down on the closure and simultaneously turning it counterclockwise (Figure 2).



Figure 2A

Figure 2B

The manufacturer's instructions on the closure are (Figure 2A):

CLOSE TIGHTLY (with arrow above it pointing clockwise)
WHILE PUSHING DOWN TURN (with arrow below it pointing counterclockwise)

An alternate cap (Figure 2B) has pictorial instructions. There is an arrow labeled "1" pointing down onto the cap and a second arrow labeled "2" wrapping around the cap in a counterclockwise direction.