




magcorp

Magnesium Corporation of America



MagCorp & Air Liquide



CAPTURE AND RECYCLING OF SULFUR HEXAFLUORIDE






magcorp


Magnesium Corporation of America



HOLDING PONDS




DESULFATION




DEBORONATION


SOLAR PONDS




SPRAY DRYING



MELTING/PURIFICATION



ELECTROLYTIC



CAST HOUSE

CONCENTRATE/PREHEAT




magcorp

Magnesium Corporation of America



Membrane Air Separation

- Hollow fibers allow:
 - high packing densities
 - operation at elevated pressures
- Permeable gases migrate across the fiber wall





magcorp

Magnesium Corporation of America



Membrane Air Separation

- Fibers produced from polymers
- Diameter of a human hair
- Up to 750 miles of fibers are assembled in a membrane module
- Thin skin at the outside of each fiber acts as a membrane to separate the constituents of a gaseous stream




magcorp


Magnesium Corporation of America



Membrane Air Separation



Cut of a hollow fiber



Membrane modules

1", 2", 6", and 12" diameter




magcorp

Magnesium Corporation of America



Floxal SF₆ Recycle System





magcorp


Magnesium Corporation of America



Oxygen, carbon dioxide, nitrogen,
etc.

Concentrated SF₆
Balance nitrogen

Exhaust
gas





magcorp

Magnesium Corporation of America



Pilot Unit Used at MagCorp





magcorp


Magnesium Corporation of America



MAGCORP'S CASTING SYSTEM

HOT ZONE

COLD ZONE





magcorp

Magnesium Corporation of America



Air Liquide's Preliminary Testing

- Measurement of exhaust gas
 - composition
 - temperature
 - pressure
 - particulate
- Determine maximum suction flow rate using a simulated compressor apparatus



magcorp

Magnesium Corporation of America



Air Liquide's Analytical Equipment



- FT-IR
 - all compounds aside from Cl_2 , F_2 , and SF_6
- UV-Vis
 - only for Cl_2 and F_2
- ND-IR
 - only for SF_6



magcorp

Magnesium Corporation of America



Air Liquide's Findings

- Concentrations of SO_2 , CO , and HCl were detected
- Neither HF or F_2 were detected
- Particulate
 - 10 μm filter exposed for 15 hours at 60 scfm
 - size ranged from 5 - 350 μm
 - composed of C, Mg, O, S, and Fe




magcorp

Magnesium Corporation of America



Air Liquide's Findings



- Cover gas diluted by a factor of 10
- Maximum suction rate of 60 scfm
- Increased amount of SF₆ for recovery from 33% to 46% with addition of 3 bottom suction ports



magcorp

Magnesium Corporation of America



Floxal SF₆ Recycle System

- Makes it possible to adjust the purity of the gas
- The lower the purity, the higher the quantity of gas produced
- C and G membrane bundles available
 - C bundle - 90% plus recovery
 - G bundle - 95% plus recovery



magcorp

Magnesium Corporation of America



Performance of Pilot Floxal SF₆ Recycle System



- Concentrated exhaust gas by 10 times
- Demonstrated 90% plus recovery of SF₆
- Test unit stream data

Streams	SF ₆	Flow Rate (scfm)
Inlet Line	0.04%	17.6
Permeate, Vent Line	0.003%	16.0
Product Line	0.4%	1.6
SF ₆ Recovery Rate	+90%	-




magcorp

Magnesium Corporation of America



Minor Issues

- Pretreatment
 - Packed tower and inlet filtration pluggage



- Corrosion of compressor hoses and fittings



magcorp

Magnesium Corporation of America



Pretreatment Options

- Packed tower alternatives
 - inlet filtration before packed tower
 - replace major components with corrosion resistant materials
 - zeolite impregnated with KMnO_4
 - activated carbon impregnated with NaOH or KOH
 - wet scrubber
- Inlet filtration alternatives
 - self-cleaning filters
 - electrostatic precipitator




magcorp


Magnesium Corporation of America



Future Experimentation



- Empirical determination of SF_6 reduction
- Expanding use
 - conventional cast machines
 - direct chill (DC) casting of magnesium





magcorp

Magnesium Corporation of America



Conclusion

- Indicated to be low maintenance and nearly a trouble free unit
- 90% plus recovery was obtained of captured gas
- Exhaust gas concentration of SF₆ was increased by 10 times
- Capable of reducing SF₆ consumption by 41%
- Neither HF or F₂ was detected
- Successful project with further experimentation