U.S. Environmental Projection Agency, Office of Research and Development SAFE AND SUSTAINABLE WATER RESOURCES RESEARCH PROGRAM



Impacts of Early-Stage Drinking Water Treatment on Cyanobacterial Toxin Release and Degradation

Nicholas R. Dugan¹, Samantha J. Smith², Toby T. Sanan¹, Gulizhaer Abulikemu², Darren A. Lytle¹

Project funded by the US Environmental Protection Agency's Region 5 office through the Regional Applied Research Effort (RARE) program

> ¹US Environmental Protection Agency ²Pegasus Technical Services

US Environmental Protection Agency Region 5 Harmful Algal Blooms Workshop Chicago, IL

April 28, 2016

Presentation outline

- Background information
- Research goals
- Methods
- Results

€PA

- How do our results compare to work performed by other groups?
- How do we interpret and apply the information?







Background: potassium permanganate and powdered activated carbon

- Potassium permanganate (KMnO₄):
 - Taste and odor control
 - Control of zebra mussels in intake structures
 - Potentially induces oxidative stress in cyanobacterial cells \rightarrow may lead to the release of toxins into solution
 - Oxidizes toxins released into solution
- Powdered activated carbon (PAC):
 - Taste and odor control
 - Control of trace organics (herbicides, insecticides, etc.)
 - Adsorbs cyanobacterial toxins released into solution
 - Neutralizes KMnO₄

Research goals

- Investigate the interaction of KMnO₄, pH, PAC and turbidity on the release and subsequent degradation of cyanobacterial toxins from intact *M. aeruginosa* cells
- KMnO₄: 1, 2.5 and 5 mg/L
- pH: 7 and 9

€PA

- PAC: 0 and 10 mg/L
- Turbidity: < 0.1, 5 and 20 NTU



Three primary jars sampled @ t = 0, 15, 30, 90 minutes. PAC flasks sampled @ t = 90 minutes



Methods

- Microcystins analyzed by enzyme linked immunosorbent assay (ELISA):
 - Total
 - 3 x freeze thaw cycles at -20 °C
 - Centrifuge \rightarrow analyze supernatant
 - Extracellular
 - Filter through glass fiber filter \rightarrow analyze filtrate
- Cell membrane status:
 - SYTOX Green stain
 - Permeates compromised cell membranes and binds with DNA
- Chlorophyll-a:
 - Filter through glass fiber filter (same filter used for extracellular toxin determination
 - Disrupt filter and cells, extract into organic solvent, measure fluorescence



Methods

- Total cells:
 - -Manual count under microscope
 - -Hemacytometer
 - -400X magnification
- Phycocyanin:
 - -In vivo, non-extractive analysis





Office of Research and Development

Results

































PAC impact on SYTOX (+) response as a function of pH, turbidity and $KMnO_4$ dose







Office of Research and Development

How do our results compare?



Fan et al, Chemosphere 2013:92:5:529-534. Impact of Potassium Permanganate on Cyanobacterial Cell Integrity and Toxin Release and Degradation



Fig. 3. Intracellular and extracellular microcystin concentrations after treatment with $KMnO_4$ (up to 7 h contact time) with $KMnO_4$ at concentrations of (a) 1 mg L⁻¹; (b) 3 mg L⁻¹; (c) 5 mg L⁻¹; and (d) 10 mg L⁻¹. Error bars equal ± standard deviation.



Ding et al, ASCE Journal of Environmental Engineering 2010:136:1:2-11. Release and Removal of Microcystins from *Microcystis* During Oxidative-, Physical-, and UV-Based Disinfection





How do our results compare?

Group	KMnO ₄ dose (mg/L)	рН	Target cell titer (x 10 ⁶ /mL)	Aqueous medium	Toxin analysis	Result
USEPA, 2016	1, 2.5, 5	7 and 9	1.0	De-Cl ₂ tap water	ELISA	Extracellular toxin release and accumulation at all KMnO ₄ doses
Fan et al, 2013	1, 3, 5, 10	7.5	0.7	ASM-1 growth medium	LC-UV	Extracellular toxin release and accumulation at 5 and 10 mg/L KMnO ₄ doses
Ding et al, 2010	I - 2	7.6	2.0	Buffered saline	LC-MS	No extracellular toxin release or accumulation observed



How do we interpret and apply the information?

Interpret and apply

- Evidence has been generated that cyanobacterial cells can release toxins when exposed to KMnO₄
- Observed magnitudes of releases and conditions under which releases occur vary between research groups
- Released toxins react with residual KMnO₄
- Released toxins adsorb onto PAC

€PA

 Drinking water treatment personnel should be cognizant of these mechanisms

Interpret and apply

• Maintain vigilance:

SEPA

- Monitor for cyanobacterial biomass and toxins at plant intake
- Monitor for toxins (total and extracellular, if possible) through treatment process once toxins detected at intake
- Think through contingency issues:
 - What do I do if I detect an extracellular toxin release?
 - Can I shut off my KMnO₄ for a day? One week? Two weeks?
 - How much can I boost my PAC feed before I have problems with my feeders, problems with my sludge and carry-over to my filters?
 - Where am I with respect to DBP compliance? How much could I boost my chlorine dose before I hit non-compliance?

• EPA's Drinking Water Optimization Team (OGWDW, Technical Support Center, Cincinnati, OH) recently initiated a project with Ohio EPA to:

€ EPA

- Develop evaluation tool to assess how prepared a system is for a HAB event
- Identify "factors" which may limit a system's ability to effectively treat a HAB
- Process will be based on turbidity optimization concepts and approach – with a strong emphasis on the importance of optimizing plant processes (clarification, filtration) for turbidity, while including considerations for treating HABs.

€PA

Disclaimer

U.S. Environmental Protection Agency, through its Office of Research and Development, funded and managed, or partially funded and collaborated in, the research described herein. It has been subjected to the Agency's peer and administrative review and has been approved for external publication. Any opinions expressed in this paper are those of the author(s) and do not necessarily reflect the views of the Agency, therefore, no official endorsement should be inferred. Any mention of trade names or commercial products does not constitute endorsement or recommendation for use.





Office of Research and Development

Supplementary material



Methods

- Cells cultured in BG-II growth medium
- Centrifuged, washed 3X, and resuspended in de-Cl₂ tap water
- De-Cl₂ tap water buffered to pH 7 and 9 with phosphate and borate buffers, respectively
- T = 20 22 °C
- 2L glass beakers on a Phipps & Bird jar test apparatus equipped with steel paddles
- 30 rpm stirring speed



Methods: Initial de-Cl₂ water quality (prior to adding *M. aeruginosa* suspension)

	Mean
Parameter	(mg/L)
NO ₃ -	0.73
NO ₂ -	< 0.012
NH4 ⁺	< 0.031
PO ₄ ³⁻	0.17
Hardness (as CaCO ₃)	110
Total organic carbon	0.80