

# **AVERT Future Year Scenario Template**

U.S. Environmental Protection Agency State Energy and Environment Program





### **AVERT's Modules and Data Files**

Raw Hourly
Generation and
Emissions Data from
Air Markets Program
(AMP) Dataset

Text files

### Future Year Scenario Template

User interface for retirements, additions, and retrofits

Excel workbook

### AVERT: Statistical Module

Inputs AMP
data, performs
statistical
analysis, outputs
new Regional
Data Files

MATLAB Code

### Regional Data Files

Contains annual hourly load data and unit-level statistics on generation and emissions data

Text files

#### AVERT Main Module

User interface
for creating
EE/RE load
curves, performs
displaced
emissions
analysis, creates
output charts
and tables

Excel workbook or web-based version

Most users will only need to use the Regional Data Files and AVERT Main Module to calculate emissions



## AVERT Future Year Scenario Overview

### Purpose

- AVERT is not forwardlooking: cannot predict EGU retirements, new additions, or emissions modifications.
- Future Year Scenarios allow users to
  - Remove EGU from analysis.
  - Include additional proxy EGU.
  - Modify emissions characteristics.

- Advanced use of AVERT
  - Excel spreadsheet
  - Read into AVERTStatistical Module
- Each spreadsheet becomes a scenario.
  - Spreadsheet becomes input file for AVERT
     Statistical Module.
  - Each future year scenario template is specifically designed to match the same historic base year.





## Use AVERT Future Year Scenario in Statistical Module

- Obtain Future Year Scenario Template (slides 5-8).
- Modify Future Year Scenario Template (slides 9-11).
- Save Future Year Scenario Template with a meaningful name.
- Run Statistical Module (slides 13-16).
  - Provide a unique name for the statistical module run (slide 13).
  - Choose saved future year scenario (slide 15).





## AVERT Statistical Module Obtain Correct Version

- AVERT Statistical Module is sensitive to PC specifications.
- Requires 64-bit operating system.
- Obtain correct version of MCR from Mathworks:
   R2012b (8.0).
  - Use the exact version noted on the AVERT website and in the user guide. An older or newer version will give you an error when you try to run the analysis.


- Determine if your
   Windows system
   operates in a 32-bit or
   64-bit environment.
  - Find this information in "properties" of "My
    Computer" in Windows XP, or "Computer" in Windows
    Vista, Windows 7, or
    Windows 8.
  - Follow these instructions:
     <a href="http://windows.microsoft.c">http://windows.microsoft.c</a>
     <a href="http://om/en-us/windows7/find-out-32-or-64-bit">om/en-us/windows7/find-out-32-or-64-bit</a>.






# AVERT Statistical Module Unpacking and Startup

 Download the AVERT Statistical Module package.



 Run the executable to decompress the package to three files and three subfolders.






To obtain historical base years, visit <a href="https://www.epa.gov/statelocalenergy/download-avert">https://www.epa.gov/statelocalenergy/download-avert</a> and obtain both the CAMD input file and the Future Year Scenario Template for that same year.



# AVERT Statistical Module File Structure

- AVERT Future Year
   Scenarios
  - Excel-based input files for altering EGU
- AVERT Output
  - Statistical Module output files
  - These become Main Module input files (Excel version)
- CAMD Input Files
  - Processed CAMD data files
  - New versions expected 2<sup>nd</sup> quarter annually
- AVERT\_StatMod\_ 2012\_v1\_64bit
  - Executable







### **Obtaining Other Base Years**

"CAMD Input Files"

To obtain additional historical base year data, visit: <a href="https://www.epa.gov/statelocalenergy/download-avert">https://www.epa.gov/statelocalenergy/download-avert</a>

Download AVERT Future Year Scenario for the AVERT Future Year Scenarios same historic base year. AVERT Output Place the file in CAMD Input Files "AVERT Future Year Scenarios" AVERT StatMod 2012 v1 64bit\_package Download the CAMD AVERT\_RegionNames input file for the historic AVERT\_StatMod\_2012\_v1\_64bit base year. readme Place the file in



**Note:** Historical base years must match up with the Future Year Scenario Template.



## AVERT Future Year Scenario Retires and Modifications


2	Retiring Units / Emission Modifo	ations													
3				Enter an option manually in blue cel			]								
	Facility Name	ORSPL U		Retire?	Retire (binary)	Revise Emissions Rates?			Revised NOx Rate (lbs/MWh)		Revised PM2.5 Rate (Tons/MMBTU)	AVERT Region	capacity -	unit typ€ → CF	<b>v</b>
5	Healy Power Plant	6288		l No	0	No	0	0.000	0.000	0.000	0.000		0 0	Coal	0%
6	Healy Power Plant	6288		2 No	0	No	0						0 0	Other	0%
7	AMEA Sylacauga Plant	56018		l No	0	No	0					Southeast	49	Gas	6%
8	AMEA Sylacauga Plant	56018		2 No	0	No	0					Southeast	49	Gas	5%
9	Ascend (Decatur Plant)	880041	X01	5 No	0	No	0					Southeast	0	Coal	0%
10	Ascend (Decatur Plant)	880041	Z00	5 No	0	No	0					Southeast	0	Coal	0%
11	Ascend (Decatur Plant)	880041	Z00	6 No	0	No	0					Southeast	0	Coal	0%
12	Barry	3		No	0	No	0					Southeast	58	Gas	2%
13	Barry	3		2 No	0	No	0					Southeast	56	Gas	2%
14	Barry	3		4 No	0	No	0					Southeast	354	Coal	36%
15	Barry	3		5 No	0	No	0					Southeast	791	Coal	46%
16	Barry	3	6/	A No	0	No	0					Southeast	291	Gas	83%
17	Barry	3	6	B No	0	No	0					Southeast	288	Gas	78%
18	Barry	3	7/	A No	0	No	0					Southeast	288	Gas	82%
19	Barry	3	7	B No	0	No	0					Southeast	288	Gas	83%
20	Calhoun Energy Center	55409	CT	Yes	1	No	0					Southeast	163	Gas	4%
21	Calhoun Energy Center	55409	CT	2 Yes	- 1	No	0					Southeast	164	Gas	2%
22	Calhoun Energy Center	55409	CT	3 No	0	No	0					Southeast	165	Gas	3%
23	Calhoun Energy Center	55409	CT	4 No	0	No	0					Southeast	161	Gas	5%
24	Charles R Lowman	56		No	0	Yes	- 1	1.000	1.000	1.000	1.000	Southeast	80	Coal	3%
25	Charles R Lowman	56		2 No	0	Yes	I	1.000	1.000	000.1	1.000	Southeast	239	Coal	30%
26	Charles R Lowman	56		3 No	0	Yes	I	1.000	1.000	000.1	1.000	Southeast	241	Coal	43%
27	Colbert	47		l No	0	No	0					Southeast	170	Coal	16%
28	Colbert	47		2 No	0	No	0					Southeast	156	Coal	17%
29	Colbert	47		3 No	0	No	0					Southeast	164	Coal	11%
30	Colbert	47		4 No	0	No	0					Southeast	163	Coal	9%



- Find EGU of interest, or filter by state or region.
- To retire, select "Yes" in the "Retire?" column.
- To change emissions rate, select "Yes" in the "Revise Emissions Rates?" column and enter new rate(s) in columns I, J, K, or L.



# AVERT Future Year Scenario Additions





#### In order


- 1. Select region
- 2. Select fuel type
- 3. Select generator type

4. Select specific EGU (unit)

Description will appear about EGU type automatically.



# **AVERT Future Year Scenario Additions**






- Choose proxy unit capacity (will scale all other factors)
- Choose state (within region)
- Choose county (within region)
- Save file



## Use AVERT Future Year Scenario in Statistical Module

- Run Statistical Module (slides 13-16).
- Provide a unique name for the statistical module run (slide 13).
- Choose saved future year scenario (slide 15).








# AVERT Statistical Module Input Parameters

- Higher number of Monte Carlo (MC) runs reduces noise.
  - For test runs, use a low number of MC runs (10) and generation-only MC runs (5).
  - For final runs, use a high number of MC runs (1,000) and generationonly MC runs (500).
- Select "Y" to write output and save runs.



Use letters and numbers only.


No special characters and no spaces.





### AVERT Statistical Module Choose Data File

- Choose base year for analysis.
  - Data from 2007 through 2018 are available.
  - New data will be ready by the second quarter of the next year.
    - Requires data to be vetted by EPA and post-processed.








### AVERT Statistical Module Choose Future Year Scenario

- Select either
  - Saved future year scenario
  - Present year analysis




Present year analysis makes no modifications to the AVERT dataset.

- Uses EGU that exist in data year
- No changes in emissions rates





### AVERT Statistical Module Choose Region(s) of Interest



- Choose region (or multiple regions) of interest.
- Same regions as in AVERT Main Module
- Once you hit "OK", the program will run uninterrupted until completion.
  - Program returns updated run status on a regular basis.

AVERT Model

- Output graphic and file indicate
  - successful completion.

