



Fountain Quail
WATER MANAGEMENT

Note: this document may contain some elements that are not fully accessible to users with disabilities. If you need assistance accessing any information in this document, please contact ORD_Webmaster@epa.gov.

Successful Oilfield Water Management 5 Unique Case Studies

Brent Halldorson
Fountain Quail Water Management



EPA Technical Workshop - Wastewater Treatment and Related Modeling
Research Triangle Park, NC. April 18, 2013


Charting a Logical Path

Saltwater

- Lower cost (minimal treatment).
- Difficult logistics (storage + transport)

Freshwater

- Higher cost (thermal distillation).
- Lower risk – store and transport freshwater.



Case Study A

Freshwater #1 – Devon Energy Barnett Shale TX

Background:


- Early on everyone used freshwater for fracs.
- Disposal was limited (until Ellenburger used for disposal).
- Devon has a large acreage position held by production.
- FQWM had to become very efficient to compete with low cost Ellenburger disposal.

Objectives:


- ① Move recycling (disposal + freshwater) close to drilling activity.
- ② Frac with freshwater (minimal storage & transport issues).
- ③ Reduce disposal volume.
- ④ Tie in nearby well flowback & PW using poly pipe.

Barnett

- Over 900 million gallons of flowback + PW recycled back to distilled water.
- Move recycling with Devon's drilling program.

An aerial photograph of an industrial site, likely a water recycling facility. The site is surrounded by green grass and has several paved areas with various pieces of equipment, including trucks, trailers, and large storage tanks. A blue oval highlights a central area containing a large circular tank and several buildings. A red arrow points from the top left towards the site, and another red arrow points from the bottom left towards the site. A dark blue text box is overlaid on the right side of the image, pointing to the highlighted area.

Fountain Quail Mobile
NOMAD Recycling Facility.

An aerial photograph of an industrial site, similar to the one above. It shows a large paved area with many vehicles, including trucks and trailers, and some buildings. A red arrow points from the bottom left towards the site.

3 Hydraulic Fracture Stimulations
using distilled & fresh water

Case Study B

Freshwater #2 – PW Into Freshwater, Upper Wolfcamp TX

Background:

- Customer has 17 wells tied into central SWD. Dispose of 5,000-7,000bpd.
- Freshwater is limited and costly. Customer prefers fracing with and handling freshwater.
- Heavy brine (9.5-10#) has value to operator and others in the region.
- Early flowback hauled long distance to disposal.

Objectives:

- ① Use PW as source water to create freshwater using NOMADs. Become independent of groundwater.
- ② Reduce SWD volume & extend SWD life.
- ③ Re-use NOMAD concentrate brine (9.5#) for drilling & completions.
- ④ Treat high-solids flowback near source.


Case Study B



- Evaporation rate is very high (dry, windy).
- Nature concentrates NOMAD waste brine to 10# *at no cost*.



Recycling Center – Hub for Water



Case Study C

Saltwater #1 – Eagle Ford Shale TX

Background:

- The Eagle Ford is in “drill-to-hold” mode.
- Producers need a very mobile solution and can re-use saltwater in nearby fracs.
- Customer objective was to clean flowback and PW for re-use (high capacity, low cost).
- Remove TSS, iron and polymers.

Objectives:

- ① Test flowback (early, middle and late) and PW removal efficiencies at the well site level.
- ② Set-up in 12 hours and be ready for flowback.

Case Study C

High capacity
(10,000bpd).

Solids removed prior to
re-use.



Eagle Ford Flowback				
Parameter	Metric	Influent to ROVER (Feed)	Effluent from ROVER	Removal
Alkalinity	mg/L CaCO ₃	406	206	49%
Iron (Fe)	mg/L	83	trace	100%
Manganese (Mn)	mg/L	1.2	trace	100%
Total Hardness (Ca+Mg)	mg/L	1025	602	41%
Silica (SiO ₂)	mg/L	148	27	82%
Total Suspended Solids (TSS)	mg/L	180	19	89%
Turbidity	NTU	>100	3	n/a
pH	pH	6.8	6.8	n/a
Total Dissolved Solids (TDS)	mg/L	32,835	34,610	n/a

Case Study D

Saltwater #2 – Woodford/Cana OK


Background:

- Wells are drilled in “Rows”. All flowback along each row is hard-pipe connected to tanks for re-use.
- Upon completion of a Row, the PW from that Row is connected to the next for re-use.
- The flowback and PW can easily be cleaned with the ROVER prior to re-use (TSS/polymer).

Study Objectives:

- ① Remove TSS from incoming flowback and PW prior to re-use.
- ② Prevents expensive clean-up when moving tanks from old Row to new Row.
- ③ Improve frac performance (reduce scaling index).
Difficult to quantify value.


Case Study D




Case Study D




ROW 1



Q: Should TSS, Fe & Polymer be removed prior to re-use?



ROW 2



100% Re-Use for Well #2

Case Study D

- Water formed good floc using FQWM standard treatments.
- Turbidity dropped from 600 NTU to 5 NTU.
- Proposed ROVER Treatment cost: \$0.79/bbl.



Customer opted to continue “as-is” and re-use the water without treatment. They recognize that high solids has potential negative impacts for production, but they cannot quantify whether improved water quality will affect production.

Re-use without treatment can be a valid water management strategy.

Case Study E

Saltwater #2 – RO Brackish, Wise County, TX

Background:


Customer challenged us with this problem:

- They have an area in northern Wise County with limited freshwater.
- There are saltwater wells available.
- They prefer to have a large freshwater pond and use freshwater if possible.
- Is it economic to try to go to freshwater?

Study Outcome:


- ① Budget cost: \$0.50/bbl for RO.
- ② RO recovery increased by blending up to 2,000mg/L TDS into the “freshwater” pit.
- ③ The RO reject is sent to NOMAD treatment and is handled along with flowback and PW.

Case Study E



Flexibility

ROVER



ROVER
Mobile Clarifier
(10,000bbl/d capacity)


1

TSS Removal
TSS + TDS Removal


2



NOMAD
NOMAD Mobile Plant
(2,000bbl/d capacity)



3



Central Plant
(60,000bbl/d capacity)

New Trends

- Pit covers (prevent evaporation).
- Combine Recycling & Disposal (not Recycling *OR* Disposal).
- More use of brackish water and saltwater – be careful about hydrogeology.
- Have a common sense discussion with parties involved:
 - Landowners are often writing leases stating that E+Ps must buy groundwater from them.
- Incentivize, not mandate recycling (i.e.: TWRA).
www.txwra.org

What is Needed?

1. Common Sense Approach.

- ▶ Ask the right questions & keep it simple (saltwater or freshwater).

2. Range of Solutions.

- ▶ Look for a proven track record. Talk to the customers.
- ▶ Technology must be based on real science backed up with real results.

3. Flexibility.

- ▶ Solution must be adaptable to the changing needs of the industry.

4. Cooperation.

- ▶ Share results and experiences (good and bad). We can learn as much, or more, from what has not worked.